

TITLE  
TOP EYE REPLACEMENT

TOOLS REQUIRED

- T1. Steel rule
- T2. Circlip pliers
- T3. 17 mm spanner
- T4.
- T5.
- T6.
- T7.
- T8.
- T9.
- T10.

ACCESSORIES REQUIRED

- A1. White grease HSW100
- A2.
- A3.
- A4.
- A5.
- A6.
- A7.
- A8.
- A9.
- A10.

# INSTRUCTIONS

1. Note spring preload and damper setting so can be reset [T1]
2. Remove spring by winding off preload and removing snap ring [T2]
3. Lift bump stop and undo locknut [T3]
4. Unscrew top eye sub-assy
5. On new top eye sub-assy, turn adjuster knob to full soft
6. Turn knob exactly 2.5 turns from full soft
7. Spray internal thread with white grease [A1] – if not done so in factory
8. Screw locknut onto piston rod as far as it will go
9. Screw on top eye sub-assy being careful not to turn adjuster knob
10. Back top eye off 0.5 turns
11. Turn shock upside down so top eye is in vice
12. Tighten locknut against top eye [T3] allowing for slight piston rod rotation
13. Remove from vice
14. Turn adjuster to full soft counting number of clicks – should be 22 minimum
15. Turn to full hard then back off to 10 from full hard or reset to desired setting
16. Refit spring with top collet
17. Replace top collet snap ring [T2]
18. Reset spring platform position [T3]
- 19.
- 20.
- 21.
- 22.
- 23.
- 24.